



FITTING INSTRUCTIONS

- 1- Flush nomad tank out with a small amount of fuel to remove any plastic particles.
- 2- Place nomad tank on rear guard moving it around so it finds its best fit.
- 3- Fit straps to bracket pins.
- 4- Hold bracket down in front of Nomad tank with strap pins facing forward with bolt hole in centre of guard. Leave about 5mm gap between back of bracket & Nomad tank,
- 5- Mark hole on guard.
- 6- Drill 6mm hole in centre of guard.
- 7- Fit mount plate with foam gasket with thread up through the new hole in guard. Place rubber washer over thread then bracket- ss washer- nylock nut. Do it up firm.
- 8- Fit fuel line to Nomad tank.
- 9- remove breather hose from main tank (rh side of filler cap)
- 10- Sit Nomad tank in place- connect fuel line to breather outlet on main tank.
- 11- Cross straps over tank mounting hooks up under guard at rear of tank.
- 12- Fit breather hose to Nomad tank, cable tie it in place so it hangs down over LH side of guard.

When filling with fuel be sure to fill main tank first, fit fuel cap to main tank before filling Nomad tank or spillage will happen.

Enjoy your ride.

With Regards from Nomad Tanks.